



SEE PARTS LIST FOR EARLIER VALUES AND S/N CHANGES OF PARTS MARKED WITH RED TINT BLOCKS

- Waveforms:
- Some conditions as for the Amplifier circuit diagram except as follows:
1. Signal disconnected from the A input connector.
  2. ALTERNATE/CHOPPED switch set to CHOPPED for waveforms so indicated.
  3. Oscilloscope used with the M Unit set for 1  $\mu$ sec/cm free-running sweep.

MRH  
03-21-62

TYPE M PLUG-IN UNIT

B

CHANNEL SWITCHING CIRCUIT

CHANNEL SWITCHING CIRCUIT